



Tools required:

- Drill with 3/8" bit
- Phillips head screwdriver
- Tape measure
- Pencil
- Level
- Safety glasses
- Allen wrenches (*supplied*)

Parts Diagram




- A..... Pivot Post Set Screw
- B..... Pivot Head
- C..... Pivot Base Set Screw
- D..... Mounting Brackets
- E..... Mounting Plates x 2
- F..... Toggle Bolts with Screws x 4
- G..... Wood Screws x 4
- H..... Allen Wrench (*small*)
- I..... Allen Wrench (*large*)

Important Notes:

- Pivots are designed for mirrors that are $\frac{3}{16}$ " in thickness, 1" bevel with safety backer & no larger than 22 $\frac{1}{2}$ " x 31 $\frac{1}{2}$ " in overall mirror size.
- Using a mirror that is larger will void warranty and can cause posts to fall off wall.
- Improper mounting will void warranty.

Step One

Install the provided mounting plates (**E**) to the back of the mirror using the double-sided tape to adhere them securely. Ensure each mounting plate is aligned with the edge of the mirror and that the grooves of the mounting plates are positioned horizontally. Both mounting plates must be installed at the same height on both sides of the mirror. Failure to do so may result in damage to the mirror or pivot.




Step Two

Align the screws of the pivot head (**B**) to the grooves on the mounting plate (**E**). Tighten securely using the larger Allen wrench (**I**).


DO NOT OVER TIGHTEN!

Over tightening may cause mirror breakage!



Step Three

Using the smaller Allen wrench (**H**), remove the mounting bracket (**D**) from the bottom of each pivot by loosening the set screw (**C**).




* Bracket design may vary depending on pivot style

Step Four

Flip the mirror over. Measure the distance between the set screws (C) from the base of each post.


* If using a 22 1/2" x 31 1/2" mirror, distance between set screws should be at/near 24 1/2".



Step Six


Drill 4 holes using a 3/8" bit (not supplied). Install the toggle bolts (F) through the mounting bracket (D) and fasten securely to the wall. If installing into a stud, use provided wood screws (G) in place of toggle bolts.

* We recommend that the posts be installed into blocking.




Step Eight

To lock the mirror in a tilting position, use the smaller allen wrench (H) to tighten the set screw on the pivot post (A). Do this for each post.



Step Five

Using the measurement from Step 3, determine on the wall where the posts are to be mounted. Using the mounting bracket (D) & a level, mark the spots to be drilled on the wall.



Step Seven

Using 2 people, align the mirror and pivot posts onto the installed mounting brackets (D). Tighten the set screw (C) securely using smaller Allen wrench (H).

